

CIRCUIT-TEST

Triple Output Digital Display Power Supply

0–30 VDC @ 2.5A

12 VDC @ 500mA

5 VDC @ 500mA

PSA-2530D

OPERATION MANUAL

Contents

INTRODUCTION	page 2
OPERATING INSTRUCTIONS	2
OPERATING CAUTIONS	2
SPECIFICATIONS	3
FRONT PANEL DESCRIPTION	4-5
WARRANTY	6-7

Introduction

This unit is a bench top single-output power supply. The power supply has two meters; one to monitor the output voltage and one to monitor the output current.

The power supply will find wide application in schools, laboratories, and commercial engineering and testing departments, as well as with the advanced hobbyist.

Operating Instructions

- (1) Connect the instrument to an AC power source using the line cord provided and turn the power switch ON. For maximum stability, allow the instrument to warm up for at least 20 minutes.
- (2) Set the voltage and current adjustment knobs to desired output.


Operating Cautions

Please note the following cautions when using your power supply, to prevent damage to the unit.

- (1) Do not connect to equipment until all settings are complete.
- (2) Verify that the AC voltage setting is the same as your available power BEFORE you apply power for the instrument.
- (3) Do not connect a voltage that is greater than the output voltage to the terminals of the instrument.

Specifications

Output Voltage:	0 – 30 VDC / 5 VDC / 12 VDC
Output Current:	0 – 2.5A (Main output) 500mA Fixed (5V & 12V output)
Current Limiting:	0–2.5 Amps continuously variable
Load Regulation:	\pm (0.5% + 10mV)
Line Regulation:	\pm (0.5% + 10mV)
Ripple and Noise:	5mV peak to peak
Meter Ranges:	Voltage... 0 – 30V Current... 0 – 2.5A
Fuse:	Replace only with 3 Amp fast blow fuse, GMA3
Power Specifications:	120 VAC \pm 10%, 60Hz, 200 Watts
Dimensions:	150 (W) x 145 (H) x 200 (D) mm 5.91 (W) x 5.71 (H) x 7.88 (D) inches
Weight:	2.8kg / 6.2 lbs



Front Panel Description

The following is an explanation of the function of each of the front panel controls and connectors.

- (1) ON/OFF SWITCH
- (2) AMMETER
- (3) VOLTMETER
- (4) VOLTAGE O/P CONTROL
- (5) OVERLOAD INDICATOR
- (6) POWER INDICATOR
- (7) VARIABLE VOLTAGE OUTPUT TERMINALS
- (8) CURRENT ADJUST
- (9) 5V FIXED VOLTAGE OUTPUT TERMINALS
- (10) 12V FIXED VOLTAGE OUTPUT TERMINALS

Warranty

Circuit-Test Power Supplies are warranted to be free of defect in workmanship and materials for a period of two years. Should this product require any repairs within this time, return the unit freight prepaid to Circuit-Test Electronics or to a Circuit-Test distributor.

**** IMPORTANT ****

When shipping the unit, always pack the power supply in its original carton and packing materials. Then place into another carton for added protection. If the original carton and materials are not available, pack the unit in a strong carton with at least three inches of resilient packing material on all sides.

DOUBLE BOXING THE UNIT IS MANDATORY.

WE ARE NOT RESPONSIBLE FOR DAMAGES INCURRED DURING
SHIPPING DUE TO IMPROPERLY PACKAGED UNITS.

When returning a power supply include the following:

- (1) Your name, return address and phone number.
- (2) Description of problem and state whether fault is intermittent or continuous. If problem is not obvious, indicate hook-up used when problem occurs.
- (3) Indicate warranty or non-warranty. For warranty repair, include a photocopy of your purchase invoice.
For non-warranty repair, give us instructions and authorization to bill your Mastercard or Visa, or to ship the unit back to you C.O.D. for service and shipping charges.
- (4) Ship freight prepaid by COURIER ONLY. Never ship by parcel post.

CIRCUIT-TEST
ELECTRONICS

Division of R.P. Electronic Components Ltd.

TEL: (604) 482-5210 FAX: (604) 738-3002

Notes

CIRCUIT-TEST
ELECTRONICS

Division of R.P. Electronic Components Ltd.
BURNABY, BC CANADA V5J 5M8

Printed in Canada